

ASSEMBLY STEP 1

HARDWARE USED IN THIS STEP



Bolts(A) QTY: 8
HBOLT M10×70



Washers(B) QTY: 16
FW M10



Nuts(C) QTY: 8
HJNUT M10

NOTE: During each assembly step, ensure that all bolts and nuts are in place and partially threaded in before completely any one bolt.

